








List of parts for electric control box

EVR - EPR - DPR - PR

Parts Number	Description	Drawing
866148	Empty box 3 Functions	
866149	Empty box 5 or 7 Functions	
866150	Empty box 10 Functions	
866151	Front of the box 3 functions	
866152	Front of the box 5 or 7 functions without display emplacement	
866153	Front of the box 5 or 7 functions with display emplacement	
866154	Front of the box 10 functions without display emplacement	No Picture
866155	Front of the box 10 functions with display emplacement	
880755	Electric card with diode for 3 functions	No Picture
880756	Electric card with diode for 5 functions	No Picture
880757	Electric card with diode for 7 functions	No Picture
880758	Electric card with diode for 10 functions	No Picture
880588	SWITCH APR 1016 C	3 pins, Without neutral point, locked in both position
880051	SWITCH APR 637H/2	3 pins, with neutral point, unlocked in both positions
880052	SWITCH APR 638H/2	3 pins, with neutral point, locked in one position
880053	SWITCH APR 639H/2	3 pins, with neutral point, locked in both positions
880105	SWITCH APR 646H/2	6 pins, Without neutral point, locked in both position
880050	SWITCH APR 647H/2	6 pins, with neutral point, locked in both positions
880725	Calculator without software	
880739	Display without software	
917300	Calculator with software for EVR and PR/DPR Mecanical shredders	
917301	Calculator with software for PR/DPR Hydraulic shredders	
917302	Display with software for EVR and PR/DPR Mecanical shredders	